

Standard Fitting Instructions for Over door Canopies

Mark out and pre-drill 6mm holes at approx 300mm centres along the canopy flanges (some canopies may have a tray and lid assembly).

Offer canopy up to the wall and centralise it above the door opening. Mark off the position on the wall for the bracket assembly (if brackets are to be fitted) make sure to put wood packer where you fix to wall to stop any distortion or damage to bracket when fixing. Make sure your markings are straight and level.

Offer the bracket up to the wall at each side of the door opening. Drill and plug the wall using a 7mm masonry drill bit. Screw the bracket to the wall using 3" screws and plugs.

Lift the canopy onto the brackets and centralise over the door opening. Drill and plug the wall as before, this time using 2" screws and plugs.

Cover all visible screw heads with the appropriate coloured screw caps.